

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

360122 *Nightstand*

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.





15 MINUTES

PARTS IDENTIFICATION

A NIGHTSTAND



1PC

B FEET



4PCS

C GLASS TOP



1PC

HARDWARE IDENTIFICATION

1 FLAT HEAD SCREW (Ф4 X 32mm - RBW)

4PCS

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **360122**


COASTER

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2



PAGE 3 OF 4


COASTERFURNITURE.COM

ITEM: **360122**


COASTER

ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4 COMPLETE




PAGE 4 OF 4

COASTERFURNITURE.COM

ITEM: **360122**



Inner Size of Drawer: 15.00"W x 12.50"D x 5.25"H x 0.25"T



Note: Dimension tolerance ±5%