


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

920242 FLOOR LAMP

REVISION ON:01/04/2024

PAGE 1 OF 5

ITEM:920242

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!



- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately
- 2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME

20 MINUTES


PARTS IDENTIFICATION

A	MARBLE BASE		1PC
В	LAMP BODY		1PC
С	LIGHT BULB		5PCS
D	GLASS SHADE		5PCS
HARDWARE IDENTIFICATION			
1	SCREW DRIVER		1PC
1	SCREW DRIVER TUBE WRENCH		1PC
2	TUBE WRENCH		1PC

ASSEMBLY INSTRUCTIONS



STEP1 STEP2



As a safety feature, and to reduce the risk of electric shock, this portable lamp includes a polarized plug (one blade is wider than the other). The plug will fit into a polarized outlet in a single direction only. If the plug does not fit fully in the outlet, reverse the plug and try again. If it still does not fit, contact a qualified electrician. DO NOT use with an extension cord unless, can be fully inserted. DO NOT alter the plug


FLOOR LAMP: TYPE A LED BULB 9W

ITEM:920242

ASSEMBLY INSTRUCTIONS








As a safety feature, and to reduce the risk of electric shock, this portable lamp includes a polarized plug (one blade is wider than the other). The plug will fit into a polarized outlet in a single direction only. If the plug does not fit fully in the outlet, reverse the plug and try again. If it still does not fit, contact a qualified electrician. DO NOT use with an extension cord unless, can be fully inserted. DO NOT alter the plug

FLOOR LAMP: TYPE A LED BULB 9W





Note: Dimension tolerance ±5%