


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 08/15/2024

PAGE 1 OF 9

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.





ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 224850KE(B1)

| 1 | MEDIUM BOLT (Φ5/16" x 45MM - BLK) | | 6PCS |
|---|--|---|------|
| 2 | BIG LOCK WASHER (Φ5/16" x 12 x 2MM - BLK) | Ċ | 6PCS |
| 3 | BIG FLAT WASHER (Ф5/16" x 19 x 2MM - BLK) | | 6PCS |
| 4 | ALLEN WRENCH (M4 x 58MM - BLK) | | 1PC |

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 224850KE(B2)

| 5 | WOODEN DOWEL (Φ10 x 40MM) | | 8PCS |
|----|---|--|-------|
| 6 | SHORT BOLT (Φ1/4" x 32MM - BLK) | | 12PCS |
| 7 | SMALL LOCK WASHER (Φ1/4" x 10 x 2MM - BLK) | I | 12PCS |
| 8 | SMALL FLAT WASHER (Ф1/4" x 19 x 2MM - BLK) | | 12PCS |
| 4 | ALLEN WRENCH (M4 x 58MM - BLK) | | 1PC |
| 9 | THREADED BOLT (Ø5/16" x 90MM - BLK) | | 8PCS |
| 10 | HALF ROUND NUT (26 x 12 x 8MM - BLK) | | 8PCS |
| 11 | HEX NUT (Ø5/16 x 6MM - BLK) | | 8PCS |
| 12 | WRENCH (12MM - BLK) | E Contraction of the second se | 1PC |

PAGE 3 OF 9



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION


Z-B3 (BOX 3) - HARDWARE PACK IS LOCATED IN 224850KE(B3)


| 13 | WOODEN DOWEL (Φ8 x 30MM) | | 4PCS |
|----|--|---|------|
| 14 | LONG BOLT (Φ5/16" x 65MM - BLK) | | 8PCS |
| 2 | BIG LOCK WASHER (Φ5/16" x 12 x 2MM - BLK) | I | 8PCS |
| 3 | BIG FLAT WASHER (Φ5/16" x 19 x 2MM - BLK) | | 8PCS |
| 4 | ALLEN WRENCH (M4 x 58MM - BLK) | Ĩ | 1PC |

NOTE:


Philips head screw driver is required in the assembly process; however, manufacturer does not provide this item.









ASSEMBLY INSTRUCTIONS STEP 5





STEP 6











COASTERFURNITURE.COM