

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE




Fine Furniture for every stage of life

508801 *SOFA*

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:





1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately. 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

SOFA BASE

1PC

B BACK CUSHION

2PCS

C LEG



4PCS

D MIDDLE LEG

1PC

Z HAREWARE IDENTIFICATION

1 **WASHER** (M6-SR)



8 PCS

BOLT (M6*30-GD) 8 PCS


3 **ALLEN KEY** (M6-GD)




1 PC

ASSEMBLY INSTRUCTIONS STEP 1










ASSEMBLY INSTRUCTIONS STEP 3











Note: Dimension tolerance ± 5%





ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life


508802 *LOVE SEAT*

REVISION 0: 07/29/2024

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:





1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately. 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

LOVESEAT BASE



1PC

B BACK CUSHION



2PCS

LEG



4PCS

Z HAREWARE IDENTIFICATION

1 **WASHER** (M6-SR)



8 PCS **BOLT** (M6*30-GD)



8 PCS


3 **ALLEN KEY** (M6-GD)




1 PC

ASSEMBLY INSTRUCTIONS STEP 1










ASSEMBLY INSTRUCTIONS STEP 3











Note: Dimension tolerance ± 5%

