



*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



551457
OTTOMAN

ITEM:551457

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME


5 MINUTES

PARTS IDENTIFICATION


	PART NAME	FIGURE	QUANTITY
A	OTTOMAN BASE		1PC
B	LEG		4PCS

ITEM:551457


ASSEMBLY INSTRUCTIONS
STEP 1



STEP 2




STEP 3





ITEM:551457



ASSEMBLY INSTRUCTIONS
STEP 4



STEP 5
COMPLETE



ITEM:551457



Note : Dimension tolerance $\pm 5\%$

