



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

609530CRN
CORNER

ITEM: **609530CRN**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!







1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION


A		BASE	1PC
B		LEG	4PCS
C		RIGHT BACK CUSHION	1PC
D		LEFT BACK CUSHION	1PC
E		BIG PILLOW	1PC
F		PILLOW	1PC

ITEM: **609530CRN**




ASSEMBLY INSTRUCTIONS



STEP 1





STEP 2





STEP 3 **COMPLETE**



ITEM:609530CRN



ITEM:609530CRN



Note: Dimension tolerance $\pm 5\%$