

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION: 07/24/2024

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM: 306051Q

COASTER FINE FURNITURE

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.




NOTE:

Phillips head screw driver is required in the assemply process; however, manufacturer does not provide this item.

ITEM: 306051Q ASSEMBLY INSTRUCTIONS




STEP 1




ITEM: 306051Q ASSEMBLY INSTRUCTIONS



STEP 3




STEP 4




ITEM: 306051Q ASSEMBLY INSTRUCTIONS STEP 5



9



STEP 6 COMPLETE





PAGE 5 OF 5

COASTERFURNITURE.COM

