


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 01/19/2022 REVISION 1 : 12/07/2022 REVISION 2 : 02/20/2024



COASTERFURNITURE.COM

ITEM: 215961Q ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



ITEM: 215961Q ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

1	SHORT BOLT (M6 x 30mm - BLK)		4PCS
2	MEDIUM BOLT (M6 x 35mm - BLK)		8PCS
3	LONG BOLT (M6 x 50mm - BLK)		8PCS
4	LOCK WASHER (1/4" - BLK)	0	16PCS
5	FLAT WASHER (1/4"ID x 13mm - BLK)	\bigcirc	16PCS
6	FLAT HEAD SCREW (M4 x 32mm - RBW)	()	24PCS
7	WOOD DOWEL (M6 x30mm)	0	4PCS
8	SHORT ALLEN WRENCH (M5 x 60mm - BLK)		1PC
9	LONG ALLEN WRENCH (M4 x 110mm - BLK)		1PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


PAGE 3 OF 5

ITEM:215961Q

ASSEMBLY INSTRUCTIONS



STEP 1



ITEM: 215961Q

ASSEMBLY INSTRUCTIONS





