

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

360146 **Sofa bed**

REVISION 0:05/25/2024 REVISION 1:09/25/2024 PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: 360146



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.

Please check to see that all hardware and parts are present prior to start of assembly.
Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME


30 MINUTES


PARTS IDENTIFICATION


A	SOFA	1PC	В	PILLOW	2PCS
С	ARM	2PCS	D	LEG	4PCS

HARDWARE IDENTIFICATION


BOLT 2 ALLEN WRENCH 3 WASHER 8PCS 1PC 8PCS (M8X2") (8M)(5#)







STEP 2



PAGE 2 OF 4


COASTERFURNITURE.COM


ITEM: 360146

ASSEMBLY INSTRUCTIONS











STEP 4



STEP 5















ITEM: 360146

ASSEMBLY INSTRUCTIONS

COASTER®

PRODUCT DIMENSION





Note: Dimension tolerance ±5%