

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

710578 Coffee Table



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.







PARTS IDENTIFICATION

A TOP 1PC

B LEG 4PCS

C BOTTOM SHELF 1PC

D CASTER 4PCS


HARDWARE IDENTIFICATION


1	LONG BOLT (Ø1/4" x 2" - BLK)		12PCS
2	SHORT BOLT (Ø1/4" x 1-1/4" - BLK)	(0)))))))))	8PCS
3	LOCK WASHER (1/4 x 16mm - BLK)		20PCS
4	FLAT WASHER (Ø1/4" - BLK)		20PCS
6	ALLEN WRENCH (4mm - BLK)		1PC

ASSEMBLY INSTRUCTIONS

COASTER'

STEP 1







ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE

STEP 3







ASSEMBLY INSTRUCTIONS

STEP 5









ASSEMBLY INSTRUCTIONS

COASTER

STEP 7






ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE


STEP 9 COMPLETE







Inner Size of Drawer: 17.75"W x 24.75"D X 3.25"H X 0.25"T



Note: Dimension tolerance ± 5%