


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0: 03/16/2020

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM:223261KW (B1-B3)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1.Remove hardware from box and sort by size.


2. Please check to see that all hardware and parts are present prior to start of assembly.

3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



ITEM:223261KW (B1-B3)

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1.Remove hardware from box and sort by size.

2. Please check to see that all hardware and parts are present prior to start of assembly.

3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




WARNING!

1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z - B1 (BOX 1)-HARDWARE PACK IS LOCATED IN 223261KW (B1)



6	THREADED BOLT (5/16" x 75mm - BLK)		8PCS	11 L-BRACKET (15 x 15 x 1mm - BLK)	Ø	4 PCS
7	U-SQUARE WASHER (25 x 15 x 2mm - BLK)	0	8PCS	12 SHORT FLAT HEAD SCREW (3.5 x 15mm - BLK)		8PCS
8	HEX NUT (5/16" x 17mm - BLK)		8PCS			
9	WRENCH (13MM - BLK)	5	1PC			
10	LONG FLAT HEAD SCREW (4 x 32mm - BLK)		8PCS			
NOTE: Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.						

PAGE 3 OF 5



