


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0: 06/20/2024

PAGE 1 OF 7

COASTERFURNITURE.COM

ITEM: 306030Q



ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



ITEM: 306030Q ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.


HARDWARE IDENTIFICATION


1	THREADED BOLT (Ø5/16" x 90mm - BLK)		14PCS	6	SHORT FLAT HEAD SCREW (M4 x 30mm - BLK)	-munur>	8PCS
2	CURVED WASHER (Ø5/16" - BLK)	0	8PCS	7	LONG FLAT HEAD SCREW (M4 x 50mm - BLK)		8PCS
3	HEX NUT (Ø5/16" - BLK)		14PCS	8	WRENCH (14mm - BLK)		1PC
4	BIG FLAT WASHER (Ø5/16" - BLK)	0	6PCS	9	SMALL FLAT WASHER (Ø1/4" - BLK)	Ø	8PCS
5	LOCK WASHER (Ø5/16" - BLK)	\bigcirc	6PCS				


NOTE:

Phillips head screw driver is required in the assemply process; however, manufacturer does not provide this item.












ITEM: **306030Q** ASSEMBLY INSTRUCTIONS STEP 7







STEP 8 COMPLETE





PAGE 7 OF 7

COASTERFURNITURE.COM

