

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 11/15/2023

PAGE 1 OF 3

COASTERFURNITURE.COM

ITEM: 123139 ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME



PARTS IDENTIFICATION

		\sim	
Α	BACK FRAME		1PC
В	SEAT CUSHION WITH FRAME		1PC
С	LEFT FRONT LEG		1PC
D	RIGHT FRONT LEG		1PC
Е	FRONT STRETCHER		1PC
F	LEFT SIDE STRETCHER		1PC
G	RIGHT SIDE STRETCHER		1PC


HARDWARE IDENTIFICATION


1	LONG BOLT (Ø5/16" x 76mm - RBW)		4PCS
2	MEDIUM BOLT (Ø5/16" x 50mm- RBW)		4PCS
3	SHORT BOLT (Ø5/16" x 38mm - RBW)		2PCS
4	LOCK WASHER (Ø5/16" *1.5mm - RBW)	6	10PCS
5	FLAT WASHER (Ø5/16" *2mm - RBW)	\odot	10PCS
6	PAN HEAD SCREW (Ø4* 38mm - RBW)	()	6PCS
7	ALLEN WRENCH (Ø4* 58mm- RBW)		1PC

NOTE:

Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.





Note: Dimension tolerance ±5%