

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

## 100219 Counter Height Chair

REVISION 0: 01/10/2006 REVISION 1: 03/15/2012 REVISION 2: 04/18/2016 REVISION 3: 12/11/2020

PAGE 1 OF 4

COASTERFURNITURE.COM

# COASTER

#### ASSEMBLY INSTRUCTIONS

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

### **PARTS IDENTIFICATION**

Α	BACK FRAME	1PC
В	FRONT LEG FRAME	1PC
С	SIDE RAIL	2PCS
D1	RIGHT SIDE STRETCHER	1PC
E1	LEFT SIDE STRETCHER	1PC
F	SEAT CUSHION	1PC

#### HARDWARE IDENTIFICATION


1	ALLEN WRENCH (M4 x 110mm - BLK)	<b>√</b>	1PC
2	BOLT (M6 x 50mm- RBW)		6PCS
3	LOCK WASHER (1/4" - BLK)	@	6PCS
4	SHORT PAN HEAD SCREW (#8 X 1" - BLK)		4PCS
5	LONG PAN HEAD SCREW (#8 X 1 1/2" - BLK)	<	4PCS

#### NOTE:


Phillips head screw driver is required in the assembly process; However, manufacturer does not provide this item. Quantities shown are for one chair.



# ASSEMBLY INSTRUCTIONS STEP 1




### STEP 2




# COASTER FINE FURNITURE

### **ASSEMBLY INSTRUCTIONS**

### STEP 3




# STEP 4 COMPLETE





COASTERFURNITURE.COM





**Note: Dimension tolerance ±5%**