


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

300525KE(B1&B2)
Eastern King Bed

REVISION 0 : 11/20/2018 REVISION 1 : 08/21/2020

PAGE 1 OF 6

COASTERFURNITURE.COM



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

<u>B1(BOX1)</u>										
AV	HEADBOARD PANEL		1PC	вv	HEADBOARD LEG	\bigsip	2PCS			
B2(BOX2)										
cv	FOOTBOARD LEG		2PCS	DV	BED RAIL		2PCS			
EV	FOOTBOARD PANEL		1PC	FV	CENTER RAIL SUPPORT WITH LEVELER	←	10PCS			
GV	BED SLAT		5PCS	FBV	300525KE(B2) FROM BOX2 FOOTBOARD		1PC			
нв\	300525KE(B1) FROM BOX1 HEADBOARD COMPLETE		1PC		COMPLETE					



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B2(BOX2)-HARDWARE PACK IS LOCATED IN 300525KE(B2)


1	ALLEN WRENCH (5MM-RBW)	1PC	2	BOLT (Ø 5/16 "X32mm-RBW)	24PCS
3	HEADBOARD CORNER BRACKET -RIGHT (200mmX60mmX40mmX2mm-RBW)	2PCS	4	HEADBOARD CORNER BRACKET -LEFT (200mmX60mmX40mmX2mm-RBW)	2PCS
5	LOCK WASHER (Ø 5/16 "-RBW)) 24PCS	6	FLAT WASHER (Ø 5/16 "-RBW)	24PCS
7	FLAT HEAD SCREW (m4x30mm-RBW)	. 10PCS			

NOTE:


Phillips hesd screw driver is required in the assemply process; however, manufacturer does not provided this item.

COASTER

ASSEMBLY INSTRUCTIONS STEP 1



STEP 2




PAGE 4 OF 6


COASTERFURNITURE.COM



ASSEMBLY INSTRUCTIONS

STEP 3







ASSEMBLY INSTRUCTIONS



STEP 5



STEP 6 COMPLETE






COASTERFURNITURE.COM

PAGE 6 OF 6



Inner Size:77.00"W X 81.00"D



Note:Dimension tolerance±5%