

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

106388 Side Chair

REVISION 0 : 07/10/2024 REVISION 1 : 12/13/2024

COASTERFURNITURE.COM

ITEM: 106388

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

Α	BACK FRAME	1PC
В	SEAT CUSHION	1PC
С	RIGHT FRONT LEG WITH LABEL "R"	1PC
D	LEFT FRONT LEG WITH LABEL "L"	1PC
E	STRETCHER	2PCS

HARDWARE IDENTIFICATION

1	SHORT BOLT (M6 x 40MM - RBW)		2PCS
2	MEDIUM BOLT (M6 x 60MM - RBW)	(Ø)	4PCS
3	LONG BOLT (M6 x 80MM - RBW)		4PCS
4	LOCK WASHER (M6 x 12MM - RBW)		10PCS
5	FLAT WASHER (M6 x 19MM - RBW)		10PCS
6	FLAT HEAD SCREW (M4 x 38MM - RBW)	(4) 1111111111>	6PCS
7	ALLEN WRENCH (M4 x 100MM - BLK)		1PC


NOTE:

Quantities shown are for one chair.


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 106388 ASSEMBLY INSTRUCTIONS STEP 1






STEP 2



STEP 3



PAGE 3 OF 4


COASTERFURNITURE.COM

ITEM: 106388 ASSEMBLY INSTRUCTIONS STEP 4




a. Make sure the chair is level (adjust the chair seat up/down if necessary)


b. Fully tighten all the screw from step 2.



STEP 5




STEP 6 COMPLETE





ITEM: 106388





Note: Dimension tolerance ±5%