


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

181367
SERVING CART

REVISION 0 : 08/01/2022
REVISION 1 : 12/13/2024

ITEM:181367



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 45 MINUTES

PARTS IDENTIFICATION

A	GLASS		2PCS
B	TOP FRAME		1PC
C	BOTTOM FRAME		1PC
D	HANDLE		1PC
E	CROSSBAR		4PCS

ITEM:181367


ASSEMBLY INSTRUCTIONS

PARTS IDENTIFICATION



F


FRAME BRACKET



8PCS

G


WHEEL



2PCS

H

WHEEL WITH LOCK



2PCS








ITEM:181367

ASSEMBLY INSTRUCTIONS



Z

HARDWARE IDENTIFICATION

1	SHORT BOLT (3/16" x 9mm SR)		8PCS
2	MEDIUM BOLT (3/16" x 15mm SR)		8PCS
3	LONG BOLT (3/16" x 32mm SR)		2PCS
4	SUCTION CUP (ϕ 19 x 9mm)		8PCS
5	ROUND CAP (ϕ 18mm SR)		2PCS
6	CAP (10 x 20mm SR)		4PCS
7	ALLEN WRENCH (4mm)		1PC


ITEM:181367




ASSEMBLY INSTRUCTIONS

STEP 1


Do not tighten until each step is completed or instructed.




ITEM:181367
ASSEMBLY INSTRUCTIONS
STEP 2




STEP 3




ITEM:181367
ASSEMBLY INSTRUCTIONS
STEP 4




STEP 5



ITEM:181367
ASSEMBLY INSTRUCTIONS
STEP 6



STEP 7
COMPLETE




ITEM:181367

ASSEMBLY INSTRUCTIONS



Product Size : 527 DIA X 787 H (MM)

Product Size : 20.75" X 31"



Note : Dimension tolerance $\pm 5\%$