



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

193631
DINING TABLE

ITEM: 193631 (B1-B2)



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10

PARTS IDENTIFICATION

B1 (BOX 1)

A TOP



1PC

B2 (BOX 2)

B BASE



2PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:193631 (B1-B2)

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 193631 (B2)

1 ALLEN WRENCH		1PC
2 SHORT BOLT (M8*16mm)		8PCS
3 FLAT WASHER D20*2		8PCS

Hardware pack is located in 193631 B2

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:193631 (B1-B2)


ASSEMBLY INSTRUCTIONS





STEP 1



STEP 2



STEP 3




ITEM:193631 (B1-B2)

Extension Table

Closed size:72.75"W*38"D*30"H

Open size :96.75"W*38"D*30"H



Note : Dimension tolerance $\pm 5\%$