

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

109388
Counter Height Table

ITEM: 109388



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!








1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.







ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

A	TOP		1PC	B	LEFT BASE		1PC
C	RIGHT BASE		1PC	D	SIDE FRAME		2PCS
E	SHELF		2PCS	F	BACK PANEL		1PC
G	FRONT FRAME		1PC				

HARDWARE IDENTIFICATION

1	BOLT ($\varnothing 5/16"$ x 38MM - RBW)		20PCS	3	FLAT WASHER ($\varnothing 5/16"$ - RBW)		20PCS
2	LOCK WASHER ($\varnothing 5/16"$ - RBW)		20PCS	4	ALLEN WRENCH (M4 x 60MM - RBW)		1PC


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: **109388**

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




ITEM: **109388**

ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4




ITEM: **109388**

ASSEMBLY INSTRUCTIONS

STEP 5



STEP 6




ITEM: **109388**


ASSEMBLY INSTRUCTIONS

STEP 7

COMPLETE



ITEM: **109388**



Note: Dimension tolerance $\pm 5\%$