


**ASSEMBLY INSTRUCTION
COASTER FINE FURNITURE**



Fine Furniture For every stage of life.

950185
ACCENT CABINET

REVISION 0 : 03/01/2020
REVISION 1 : 04/21/2023
REVISION 2 : 10/16/2023
REVISION 3 : 01/17/2025

PAGE 1 OF 7

COASTERFURNITURE.COM

Assembly Instruction

ASSEMBLY TIPS:









- 1.Remove hardware from and sort by size.
- 2.please check to see that all hardware and parts are present prior to start of assembly.
- 3.please follow attached instructions in the same aequence as numbered to assure fast & easy assembly

















Warning !

- 1.Don't attempt to repair or modify parts that are broken or defective.please contact the store immediately
- 2.This product is for home use only and not intended for commercial establishment.


PARTS IDENTIFICATICON:

Z HARDWARE IDENTIFICATICON:


A	TOP PANEL		1PC
B	LEFT SIDE FRAME		2PCS
C	RIGHT SIDE FRAME		2PCS
D	FIXED PANEL		1PC
E	ADJUSTBALE PANEL		2PCS
F	LEFT DOOR		2PCS
G	RIGHT DOOR		2PCS
H	BOTTOM FRAME		1PC

NO	DESCRIPTION	FIGURE	Q`TY
1	CAM BOLT (GOLD)		20PCS
2	CAM LOCK (GOLD)		20PCS
3	WOOD DOWEL (Ø8*30MM NATURAL)		22PCS
4	ROUND HEAD SCREW (Ø3*14MM BLACK)		4PCS
5	SHELF SUPPORT (BRONZE)		8PCS
6	DOOR HANDLE (BLACK)		4PCS
7	MACHINE SCREW (Ø5/32"*16MM BLACK)		8PCS
8	HINGE (BLACK)		8PCS
9	MAGNET (BROWN)		2PCS
10	FLAT HEAD SCREW (Ø3*10MM BLACK)		48PCS
11	GLUE (WHITE)		1PC
12	PALSTIC (8mm)		1PC
13	L METAL (24 x 13 x 1.5mm)		2PCS
14	PLASTIC LINE (270mm)		1PC
15	LARGE SCREW (8 x 25mm)		1PC
16	SMALL SCREW (8 x 15mm)		1PC


STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6





STEP 7



STEP 8



STEP 9



FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.
 This restraint not a substitute for proper adult supervision.
 This restraint may provide protection against tipping furniture.
 Do not allow children to climb on furniture.
 Failure to detach this restraint before moving furniture may
 result injury and damage

ITEM:950185

