


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

REVISION 0: 12/30/2024

710750 TV Stand

PAGE 1 OF 17

IТЕМ:**710750**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning!!


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION



NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning!!


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION



Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

PAGE 3 OF 17



HARDWARE IDENTIFICATION


1	LARGE CAMBOLT (Ø7 x29mm)		8pcs
2	LARGE CAMBOLT (Ø15x12mm)		8pcs
3	WOOD DOWEL (Ø8 x 25mm)		4pcs
4	SMALL CAMBOLT (Ø6 x20mm)		20pcs
5	SMALL CAMBOLT (Ø12x10mm)		20pcs
6	WOOD DOWEL (Ø6 x 30mm)		6pcs
7	LEG WITH BOLT (Ø55 x 25mm)		5pcs
8	LARGE SCREW (Ø4 x 35mm)		14pcs
9	SMALL SCREW (Ø4x 16mm)	ACCOUNTY.	24pcs
10	STICKER (Ø22mm)		12pcs

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



ASSEMBLY INSTRUCTIONS STEP 1




STEP 2




PAGE 5 OF 17



ASSEMBLY INSTRUCTIONS STEP 3




STEP 4




PAGE 6 OF 17



ASSEMBLY INSTRUCTIONS STEP 5




STEP 6




PAGE 7 OF 17




ASSEMBLY INSTRUCTIONS STEP 7





STEP 8




PAGE 8 OF 17




ASSEMBLY INSTRUCTIONS

STEP 9




STEP 10




PAGE 9 OF 17



ASSEMBLY INSTRUCTIONS STEP 11




STEP 12




PAGE 10 OF 17



ASSEMBLY INSTRUCTIONS STEP 13




STEP 14




PAGE 11 OF 17



ASSEMBLY INSTRUCTIONS STEP 15




STEP 16



PAGE 12 OF 17




ASSEMBLY INSTRUCTIONS STEP 17



X2

STEP 18




X2


PAGE 13 OF 17



ASSEMBLY INSTRUCTIONS STEP 19




STEP 20



PAGE 14 OF 17




ASSEMBLY INSTRUCTIONS STEP 21





ASSEMBLY INSTRUCTIONS STEP 22



PAGE 16 OF 17

ITEM:**710750 DIMENSION** 15.5" 10.75" 16 13.75"

PAGE 17 OF 17