


**ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE**



Fine Furniture for every stage of life

910336
Bench

ITEM: 910336



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME

10 MINUTES


PARTS IDENTIFICATION



Z HARDWARE IDENTIFICATION


NO	DESCRIPTION	FIGURE	Q' TY
1	LOCK WASHER 1/4"		12PCS
2	FLAT WASHER 1/4"*19mm		12PCS
3	BOLT 1/4X1-1/2"		12PCS
4	ALLEN KEY 4mm		1PC

STEP: 1



ITEM: 910336

ASSEMBLY INSTRUCTIONS



Note: Dimension tolerance $\pm 5\%$