

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

REVISION 0: 12/23/2016 REVISION 1: 05/20/2019 REVISION 2: 11/30/2019

REVISION 3: 12/14/2019

REVISION 4: 07/28/2022 REVISION 5: 12/24/2024 REVISION 6: 02/06/2025 PAGE 1 OF 4

107286

SIDE CHAIR

COASTERFURNITURE.COM

ITEM: 107286

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.





ASSEMBLY TIME

10 MINUTES

LARGE BOLT

PARTS IDENTIFICATION

HARDWARE INDENTIFICATION


Α		BACK FRAME	1PC
В		SEAT CUSHION	1PC
С	••••••••••••••••••••••••••••••••••••••	FRONT LEG	2PCS

1		LARGE BOLT (M8×75mm)	4PCS
2	<u>()—————</u>	SMALL BOLT (M8×65mm)	4PCS
3	<u>(</u>	SMALL BOLT (M8×55mm)	1PC
4		ALLEN KEY (M8)	1PC
5		LOCK WASHER (Φ8)	9PCS
6		FLAT WASHER (Φ8)	9PCS

ITEM: 107286

ASSEMBLY INSTRUCTIONS





ITEM: 107286

COASTER FINE FURNITURE

ASSEMBLY INSTRUCTIONS

