

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

115531 (B1&B2)
Dining Table

ITEM: 115531(B1&B2)



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.






ASSEMBLY TIME

25 MINUTES

PART IDENTIFICATION

B1 (BOX 1)

AN	TOP		1PC
CN	TRESTLE BAR		1PC
DN	LEAF		2PCS

B2 (BOX 2)

BN	BASE		2PCS
----	------	---	------

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 115531 (B1)

1	THREADED BOLT (5/16" x 100mm - WHT)		2PCS
2	HALF ROUND NUT (22 x 17 x 10mm - WHT)		2PCS
3	HEX NUT (5/16" x 12 - BLK)		2PCS
4	HEX BOLT (5/16" x 50mm - BLK)		8PCS
5	LOCK WASHER (1.6 x 14mm - BLK)		8PCS
6	FLAT WASHER (1 x 18mm - BLK)		8PCS
7	WRENCH (M12 - RBW)		1PC
8	WOOD DOWEL (10 x 40mm - BRW)		4PCS


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: **115531(B1&B2)**

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2





ITEM: **115531(B1&B2)**


ASSEMBLY INSTRUCTIONS



STEP 3



STEP 4




ITEM: **115531(B1&B2)**


ASSEMBLY INSTRUCTIONS

STEP 5

COASTER
FINE FURNITURE



STEP 6





ITEM: **115531(B1&B2)**



ASSEMBLY INSTRUCTIONS

STEP 7


COASTER
FINE FURNITURE



STEP 8 COMPLETE



ITEM: **115531(B1&B2)**



Note: Dimension tolerance $\pm 5\%$