



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

551641 ARMLESS CHAIR

REVISION 0: 12/06/2021
REVISION 1: 03/07/2025

COASTERFURNITURE.COM

ITEM: 551641

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 15 MINUTES

PARTS IDENTIFICATION


A



ARMLESS CHAIR

1PC

B



LEG


4PCS

ITEM: 551641


ASSEMBLY INSTRUCTIONS





STEP 1





STEP 2



STEP 3



ITEM: 551641



Note : Dimension tolerance $\pm 5\%$

COASTERFURNITURE.COM