

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 11/28/2024 REVISION 1 : 03/11/2025

PAGE 1 OF 19

ITEM:706223




ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!



PAGE 2 OF 19



ITEM:706223





HARDWARE IDENTIFICATION


Ζ	-			I			
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	9	GLIDES L = 350mm BLK	CL C	2 SET
2	WOODEN DOWEL Ø8 x 30mm		60 PCS	10	GLIDES SCREW Ø 3x10mm BLK		24 PCS
3	CAM BOLT Ø7 x 35.5mm SR		28 PCS	11	HINGE Ø35mm SR	the te	4 PCS
4	CAM LOCK Ø15 x 12mm SR		28 PCS	12	HINGE SCREW Ø4 x 15mm SR	attitle	16 PCS
5	LONG SCREW Ø 4.5x42mm SR		8 PCS	13	PLASTIC COVER Ø 52mm		2 PC
6	SCREW Ø 4.3x35mm SR	attititite.	8 PCS	14	BACK PANEL SUPPORT		6 PCS
7	PLASTIC FEET Ø15m		8 PCS	15	BACK PANEL SUPPORT SCREW Ø3 x 19mm SR	A COMPANY AND A COMPANY A COMPANY AND A COMPANY AND A COMPANY AND A COMPANY A COMPANY AND A COMPANY	6 PCS
8	PIN FOR ADJUSTABLE SHELF Ø4.9x8mm SR		8 PCS	16	STICKER Ø20mm		5 PCS
Z9, Z11, Z13 not included in blister packaging.							


NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.
























ITEM:**706223** STEP 17

























COASTERFURNITURE.COM

