

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

552101
SOFA

ITEM:552101

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1.Remove wood legs from sofa bottom and sort by size.
- 2.Please check to see that parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

6 MINUTES

PARTS IDENTIFICATION

A BASE



1PC

B WOOD LEG



5PCS

C L BACK CUSHION



1PC

D R BACK CUSHION





1PC

ITEM:552101




STEP 1




ITEM:552101




STEP 2



STEP 3 COMPLETE



ITEM: 552101



Note: Dimension tolerance $\pm 5\%$