

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

COFFEE TABLE

REVISION 0: 04/01/2025

PAGE 1 OF 7




ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 35 MINUTES

PARTS IDENTIFICATION


B1: TOP

A TOP

B2: BASE

B TOP FRAME

1PC





C LEG

Z

HARDWARE IDENTIFICATION

1 SHORT BOLT (1/4" x 15mm BLK)

0

4 LEVELER (1/4" x 12mm BLK)



4PCS

2 LONG BOLT (1/4" x 56mm BLK)



5 ALLEN WRENCH (4mm)



1PC

3 SUCTION CUP



4PCS

4PCS


Hardware pack is located in 708138B2

PAGE 2 OF 7




STEP 1


Do not tighten until each step is completed or instructed.



STEP 2




PAGE 3 OF 7






STEP 5




STEP 6




PAGE 5 OF 7



STEP 7



STEP 8 COMPLETE




PAGE 6 OF 7



Product Size: 895 X 895 X 445 H (MM)

Product Size: 35.25" X 35.25" X 17.5"



Note: Dimension tolerance ±5%