

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

2065 **DINING TABLE**

REVISION 0 : 05/20/2018
REVISION 1 : 07/29/2019
REVISION 2 : 08/17/2022
REVISION 3 : 04/25/2025

PAGE 1 OF 6

COASTERFURNITURE.COM

ITEM:2065



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!





1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.







ASSEMBLY TIME

15 MINUTES


PARTS IDENTIFICATION

A	LEG 1		2PCS
B	LEG 2		2PCS
C	TRESTLE TUBE		1PC
D	TABLE TOP		1PC


HARDWARE IDENTIFICATION

1	BOLT (1/4" x 38mm)		12PCS
2	END CAP		10PCS
3	LEVELER		4PCS
4	WRENCH (4mm)		1PC

ASSEMBLY INSTRUCTIONS
STEP 1




STEP 2




ITEM: **2065**



STEP 3



STEP 4




ITEM: **2065**




ASSEMBLY INSTRUCTIONS

STEP 5

COMPLETE





Note : Dimension tolerance $\pm 5\%$