

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

109462 <u>Side Chair</u>

ITEM: 109462

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A BACK FRAME	1PC	E RIGHT FRONT LEG	1PC
B SEAT FRAME	1PC	F LEFT SIDE STRETCHER	1PC
C SEAT CUSHION	1PC	G RIGHT SIDE STRETCHER	1PC
D LEFT FRONT LEG	1PC		

HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 x 100mm - BLK)	1PC	5	LOCK WASHER (M6 - RBW)	0	10PCS
2	SHORT BOLT (M6 x 40mm - RBW)	2PCS	6	FLAT WASHER (M6 - RBW)		10PCS
3	MEDIUM BOLT (M6 x 60mm - RBW)	4PCS	7	SHORT FLAT HEAD SCREW (M4 x 25mm- RBW)	Dimension	5PCS
4	LONG BOLT (M6 x 70mm - RBW)	4PCS	8	LONG FLAT HEAD SCREW (M4 x 38mm- RBW)	Dimension	4PCS

NOTE:

Quantities shown are for one chair.


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **109462**


ASSEMBLY INSTRUCTIONS

COASTER


STEP 1




STEP 2



STEP 3



STEP 4 COMPLETE






COASTERFURNITURE.COM

ITEM: 109462





Note: Dimension tolerance ±5%