



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

551623

OTTOMAN

REVISION 0 : 11/12/2021
REVISION 1 : 08/02/2022
REVISION 2 : 07/28/2025

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: 551623

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION


	PART NAME	FIGURE	QUANTITY
A	OTTOMAN		1PC
B	LEG		4PCS

ITEM: 551623


ASSEMBLY INSTRUCTIONS

COASTER®
FINE FURNITURE

STEP 1




STEP 2





STEP 3

COMPLETE



ITEM: 551623



Note: Dimension tolerance ±5%

