



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



610151P
Power Reclining Sofa

ITEM: 610151P

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A SEAT



1PC

B LEFT BACK



1PC

C MIDDLE BACK



1PC

D RIGHT BACK



1PC

E LEFT EAR



1PC

F RIGHT EAR



1PC

G ADAPTER




1PC


ITEM: **610151P**

ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2



STEP 3
COMPLETE



ITEM: **610151P**



Note: Dimension tolerance $\pm 5\%$