

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

610360CON
CONSOLE

ITEM: **610360CON**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION


A



BASE

1PC

B



LEG

4PCS

C



POWER CORD


1PC

ITEM: **610360CON**




ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2





STEP 3



STEP 4 **COMPLETE**



ITEM:610360CON



Note:Dimension tolerance $\pm$ 5%