



*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

509887
ARMLESS CHAIR

ITEM: 509887

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.







WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 5 MINUTES

PARTS IDENTIFICATION


	PART NAME	FIGURE	QUANTITY
A	ARMLESS CHAIR BASE		1PC
B	ARMLESS CHAIR SEAT CUSHION		1PC
C	ARMLESS CHAIR BACK CUSHION		1PC
D	LEG		4PCS
E	PILLOW		2PCS

ITEM: 509887




ASSEMBLY INSTRUCTIONS


STEP 1 Turn over the item and take out the legs from zippered pouch



STEP 2 Install the legs as pictures show




STEP 3 Please remove the wood block with screwdriver,do not use a hammer



STEP 4

COMPLETE




ITEM: 509887

ASSEMBLY INSTRUCTIONS





STEP 5 Rotate the metal clips





STEP 6 Put the chaise and loveseat closer
509889B1

509889B2

509887



STEP 7 Insert the metal clips to connect other units as pictures show





STEP 8



COMPLETE

OPTION1

OPTION2



ITEM: 509887



Note : Dimension tolerance $\pm 5\%$

