

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

701833
TV STAND

ITEM:701833



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME


60 MINUTES

MAX TV SIZE : 85"

PARTS IDENTIFICATION

A


LEFT SIDE
PANEL



1 PC

B


RIGHT SIDE
PANEL



1 PC

C


MIDDLE DIVIDER
PANEL



1 PC

D


LEFT RIGHT
DIVIDER PANEL



2 PCS

E

LONG CROSS
BRACE



2 PCS

F


SHORT CROSS
BRACE



2 PCS

G


BOTTOM PANEL



1 PC

H


ADJUSTABLE
SHELF



4 PCS

I


TOP PANEL



1 PC

J


BACK PANEL



4 PCS

K

DOOR













4 PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:701833

HARDWARE IDENTIFICATION**Z**


NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	9	BOLT M4x25mm BLK		8 PCS
2	WOODEN DOWEL Ø8 x 30mm		34 PCS	10	HINGE Ø35mm SR		8 PCS
3	CAM BOLT Ø7 x 35.5mm SR		18 PCS	11	HINGE SCREW Ø4x15mm SR		32 PCS
4	CAM LOCK Ø15 x 12mm SR		18 PCS	12	BACK PANEL SUPPORT		6 PCS
5	BOLT Ø9.5x55mm SR		10 PCS	13	BACK PANEL SUPPORT SCREW Ø3 x 19mm SR		6 PCS
6	PIN FOR ADJUSTABLE SHELF Ø4.9 x 8mm SR		16 PCS	14	PLASTIC COVER Ø 52mm		4 PCS
7	PLASTIC FEET Ø15mm		6 PCS	15	STICKER Ø20mm		3 PCS
8	HANDLE L= 289mm BLK		4 PCS				

Z8, Z10, Z14 not included in blister packaging.**NOTE:**


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **701833**

STEP 1








STEP 2






ITEM: **701833**

STEP 3







INCORRECT
CORRECT



Apply glue on all wooden dowels to ensure integrity of the structure.


STEP 4





ITEM: **701833**

STEP 5

COASTER
FINE FURNITURE




STEP 6




ITEM: **701833**

COASTER
FINE FURNITURE

STEP 7





STEP 8







ITEM: 701833

STEP 9

COASTER
FINE FURNITURE









STEP 10



ITEM: **701833**

STEP 11





COASTER
FINE FURNITURE




ITEM: **701833**

STEP 12


COASTER
FINE FURNITURE



STEP 13
COMPLETE



ITEM: 701833



Note : Dimension tolerance $\pm 5\%$