COASTER
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

205337
Bench

REVISION 0 : 11/29/2016
REVISION 1 : 12/13/2018
REVISION 2 : 11/18/2019
REVISION 3 : 08/07/2020

ITEM: **205337**


ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.


WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME	10 MINUTES

PARTS IDENTIFICATION

A	SEAT CUSHION WITH FRAME		1PC
B	LEG		4PCS
C	BOTTOM FRAME		1PC

HARDWARE IDENTIFICATION


1	ALLEN WRENCH (M4 - BLK)		1PC
2	BOLT (M6 x 60mm - BLK)		12PCS

ITEM: **205337**


COASTER FINE FURNITURE

ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2




STEP 3
COMPLETE





ITEM: **205337**



Note : Dimension tolerance ±5%