COASTER®
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

610243
Glider Recliner

REVISION 0: 05/13/2023
REVISION 1: 09/27/2023

ITEM: **610243**

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1.Remove hardware from box and sort by size.


2.Please check to see that all hardware and parts are present prior to start of assembly.

3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING


1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2.This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME	5 MINUTES

PARTS IDENTIFICATION

A	SEAT		1PC
B	BACK		1PC
C	LEFT ARM		1PC
D	RIGHT ARM		1PC

HARDWARE IDENTIFICATION

1	THREADED BOLT (Φ5/16")		4PCS
2	NUT (Φ5/16"*90L)		4PCS


NOTE:

Phillips head screw driver is required in the assembly process ; however, manufacturer does not provide this item.


ITEM: **610243**

ASSEMBLY INSTRUCTIONS


STEP 1



STEP 2





STEP 3



STEP 4


COMPLETE





COASTERFURNITURE.COM

ITEM: **610243**



Note: Dimension tolerance ±5%