ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

100515GRY
Side Chair

REVISION 0 : 10/09/2019
REVISION 1 : 03/09/2023
REVISION 2 : 16/11/2023
REVISION 3 : 24/01/2024
REVISION 4 : 04/03/2026

ITEM:100515GRY

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME	15 MINUTES

PARTS IDENTIFICATION

AV	BACKREST		1PC
BV	SEAT		1PC
CV	BASE		1PC


HARDWARE IDENTIFICATION

1	LONG BOLT (Ø1/4" x 20mm - SR)		4PCS
2	SHORT BOLT (Ø1/4" x 15mm - SR)		4PCS
3	FLAT WASHER (Ø1/4" x 16mm - SR)		8PCS
4	LOCK WASHER (Ø1/4" x 12mm - SR)		8PCS
5	ALLEN WRENCH (M4 - 59mm - SR)		1PC

ITEM:**100515GRY**


ASSEMBLY INSTRUCTIONS

STEP 1



Bottom View


STEP 2



Bottom View


STEP 3

COMPLETE





ITEM:**100515GRY**



Note: Dimension tolerance ±5%