COASTER
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

122178
Counter Height Dining Table Base

REVISION 0 : 12/01/2025

COASTERFURNITURE.COM

ITEM: **122178**

ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.


WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME	15 MINUTES

PARTS IDENTIFICATION

A	LEG SUPPORT FRAME		1PC
B	LEG		4PCS
C	DISC WITH BOLT		4SETS


HARDWARE IDENTIFICATION

1	BOLT (M8 x 60MM -RBW)		8PCS
2	LOCK WASHER (M8 x 13MM - RBW)		8PCS
3	FLAT WASHER (M8 x 22MM - RBW)		8PCS
4	ALLEN WRENCH (M5 x 65MM -BLK)		1PC

ITEM: **122178**


ASSEMBLY INSTRUCTIONS

STEP 1



BOTTOM VIEW

STEP 2



ITEM: **122178**

ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4


COMPLETE



NOTE : GLASS TOP NOT INCLUDED



ITEM: **122178**



Note: Dimension tolerance ±5%