COASTER®
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE

Fine Furniture for every stage of life

182235
BAR UNIT

COASTERFURNITURE.COM

ITEM:182235
ASSEMBLY INSTRUCTIONS

COASTER
FINE FURNITURE

ASSEMBLY TIPS:
1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

⚠️ **WARNING!**
1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

| ASSEMBLY TIME | 80 MINUTES |

PARTS IDENTIFICATION

B1 : ACRYLIC PANELS, MIDDLE PANELS, DRAWER, METAL

A	LEFT FRAME	1PC
B	RIGHT FRAME	1PC
C	FRONT RIGHT FRAME	1PC
D	FRONT LEFT FRAME	1PC
E	TOP GLASS SUPPORT LEG	5PCS
F	FOOTREST SIDE LEG	2PCS

ASSEMBLY INSTRUCTIONS

PARTS IDENTIFICATION

COASTER
FINE FURNITURE

G	FOOTREST MIDDLE LEG		1PC
H	BOTTOM LEG		5PCS
I	FOOTREST MIDDLE LEG SUPPORT		1PC
J	FOOTREST PLATE		2PCS
K	BOTTLE RACK		2PCS
L	GLASS HOLDER		4PCS
M	LEFT PANEL		1PC

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

PARTS IDENTIFICATION

N	RIGHT PANEL		1PC
O	MIDDLE SHELF		1PC
P	BACK PANEL		1PC
Q	DRAWER FRONT PANEL		1PC
R	DRAWER BACK PANEL		1PC
S	DRAWER LEFT PANEL		1PC
T	DRAWER RIGHT PANEL		1PC

COASTERFURNITURE.COM

COASTER®
FINE FURNITURE

| U | DRAWER BOTTOM PANEL | | 1PC |
| V | SLIDE RAIL | | 2PCS |

B2 : GLASSES, TOP/BOTTOM PANELS, FOOTREST

A1	FOOTREST BAR		1PC
A2	TOP GLASS		1PC
A3	SHELF GLASS		2PCS
A4	TOP PANEL		1PC
A5	BOTTOM PANEL		1PC

COASTERFURNITURE.COM

ITEM:182235
ASSEMBLY INSTRUCTIONS
HARDWARE IDENTIFICATION

COASTER
FINE FURNITURE

1	LONG BOLT (φ1/4" x 32mm SR)		11PCS	11	CAM LOCK (φ15mm)		6PCS
2	MEDIUM BOLT (φ1/4" x 28mm SR)		8PCS	12	SHELF GLASS BOLT		8PCS
3	BOLT (φ1/4" x 25mm SR)		1PC	13	WOOD DOWEL (8 x 30mm)		2PCS
4	SHORT BOLT (φ1/4" x 13mm SR)		29PCS	14	LEVELER (5/16" x 15mm BLK)		3PCS
5	HANGER BOLTS		5PCS	15	GLUE		1PC
6	SMALL BOLT (φ5/32" x 12mm)		2PCS	16	BOTTOM CAP (φ25mm BLK)		5PCS
7	LONG SCREW (φ4 x 38mm)		16PCS	17	ROUND CAP (φ25mm BLK)		3PCS
8	SMALL SCREW (φ4 x 12mm)		24PCS	18	WASHER (φ1/4" SR)		5PCS
9	SLIDE RAIL SCREW (φ3.5mm x 12mm)		6PCS	19	ALLEN WRENCH (4mm)		1PC
10	CAM BOLT (38mm)		6PCS	20	HEXAGONAL KEY		1PC

Hardware pack is located in 182235B1

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

COASTER
FINE FURNITURE

STEP 1
Do not tighten until each step is completed or instructed.

1
18
18
1
A4
18
1
E
E
1
18
18
5
E
5
5
E
E
5
A2
5
5

STEP 2

C
2
B
D
8
2
2
8
A
2

COASTERFURNITURE.COM

COASTER
FINE FURNITURE

STEP 3

STEP 4

COASTERFURNITURE.COM

COASTER
FINE FURNITURE

STEP 5

M

10
10
10
10

11

11

STEP 6

1

7

1

1

1

1

A5

1

COASTERFURNITURE.COM

ITEM:182235
ASSEMBLY INSTRUCTIONS

COASTER
FINE FURNITURE

STEP 7

STEP 8

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

STEP 9

STEP 10

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

STEP 11

14
17
F
4
J
14
4
A1
4
F
J
J
17
4

STEP 12

12
A3
12
A3
12

ASSEMBLY INSTRUCTIONS

COASTER
FINE FURNITURE

STEP 13

7

15

13

S

R

11

U

T

7

11

10

13

10

13

Q

STEP 14
COMPLETE

6

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

COASTER
FINE FURNITURE

Product Size : 1499 X 600 X 1080 H (MM)
Product Size : 59" X 23.5" X 42.5"

1499 mm
59"

157 mm
6.25"

360X334X75mm | drawer
14.25" X 13.25" X 3"

338 mm
13.25"

243 mm
9.5"

420 mm
16.5"

1080 mm
42.5"

338 mm
13.25"

385 mm
15.25"

400 mm
15.75"

400 mm
15.75"

600 mm
23.5"

Note : Dimension tolerance ±5%

COASTERFURNITURE.COM