ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE

Fine Furniture for every stage of life

881281(B1&B2)
Executive Desk

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

COASTER
FINE FURNITURE

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
2. This product is for home use only and not intended for commercial establishments.

| ASSEMBLY TIME | 25 MINUTES |

# PART IDENTIFICATION

B1 (BOX 1)

A	TOP		1PC
H	SMALL DRAWER DIVIDER		4PCS

B2 (BOX 2)

B	LEFT COMPARTMENT		1PC
C	RIGHT COMPARTMENT		1PC
D	CENTER PANEL		1PC
E	LEG		8PCS
F	DRAWER HANGER		4PCS
G	BIG DRAWER DIVIDER		4PCS
I	UNIVERSAL KEY		2SETS

ASSEMBLY INSTRUCTIONS

COASTER
FINE FURNITURE

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

⚠️ **WARNING!**

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 881281(B2)

|			
1	**SHORT BOLT** (M6 x 40mm - BLK)		**14PCS**
2	**LONG BOLT** (M6 x 100mm - BLK)		**16PCS**
3	**LOCK WASHER** (1.6 x 14mm - BLK)		**30PCS**
4	**FLAT WASHER** (1 x 18mm - BLK)		**30PCS**
5	**ALLEN WRENCH** (M4 x 65mm - BLK)		**1PC**
6	**FLAT HEAD SCREW** (4 x 38mm - BLK)		**16PCS**
7	**WOOD DOWEL** (10 x 30mm - BRW)		**4PCS**

NOTE:

Philips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **881281(B1&B2)**

ASSEMBLY INSTRUCTIONS

STEP 1

B

PART # E ~ I INSIDE

STEP 2

5

2

3

4

6

E

B
&
C

B
&
C

ASSEMBLY INSTRUCTIONS

COASTER
FINE FURNITURE

STEP 3

B

B

D

D

D

C

4

3

5

1

STEP 4

REMOVE DRAWER,
BEFORE ATTACHING THE TOP

UP

DOWN

ITEM: **881281(B1&B2)**

ASSEMBLY INSTRUCTIONS

STEP 5

A

7

A

D

4

3

1

5

4

3

1

5

B

STEP 6

PUT DRAWERS BACK

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

STEP 7

H

G

F

I

STEP 8
COMPLETE

LEVELER

ITEM: **881281(B1&B2)**

Inner Size of Drawer A : 14.50"W x 17.75"D x 1.75"H x 0.50"T
Inner Size of Drawer B : 14.50"W x 17.75"D x 3.00"H x 0.50"T
Inner Size of Drawer C : 14.50"W x 17.75"D x 9.50"H x 0.50"T
Inner Size of Drawer D : 25.00"W x 10.75"D x 1.75"H x 0.50"T

Note: Dimension tolerance ± 5%