ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE

Fine Furniture for every stage of life

182136
BAR TABLE

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:
1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!
1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME	60 MINUTES

PARTS IDENTIFICATION

A	LEFT LEG		1PC
B	RIGHT LEG		1PC
C	FRONT FRAME		1PC
D	HANGER BRACKET		1PC
E	BOTTOM SUPPORT		1PC
F	GLASS SHELF SUPPORT		2PCS

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

COASTER
FINE FURNITURE

PARTS IDENTIFICATION

G	UPPER TOP GLASS		1PC
H	GLASS SHELF		2PCS
I	LOWER TOP GLASS		1PC

HARDWARE IDENTIFICATION

1	ALLEN BOLT-MEDIUM (1/4" x 8mm SR)		22PCS	7	ALLEN BOLT-LARGE (1/4" x 38mm SR)		3PCS
2	ALLEN BOLT-SMALL (1/4" x 9mm SR)		4PCS	8	NUT (1/4" SR)		3PCS
3	BOLT (3/16" x 12mm SR)		4PCS	9	WASHER (Ø16mm SR)		3PCS
4	SMALL WASHER (Ø15mm)		4PCS	10	PLASTIC WASHER (Ø26mm)		3PCS
5	SUCTION CUP (6mm)		4PCS	11	ALLEN WRENCH (4mm)		1PC
6	FLOOR LEVELER (1/4" x 6mm BLK)		4PCS	12	HEXAGONAL WRENCH (1/4")		1PC

NOTE: PART 7,8,9,AND 10 ARE NEEDED ONLY WHEN BUYING 2 UNITS

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

COASTER®
FINE FURNITURE

STEP 1
Do not tighten until each step is completed or instructed.

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

STEP 2

STEP 3

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

COASTER
FINE FURNITURE

STEP 4

STEP 5
COMPLETE

COASTERFURNITURE.COM

STEP 6   NOTE: WHEN BUYING 2 OR 3 UNITS

COASTER
FINE FURNITURE

How to clean Acrylic product:
Using a dry soft microfiber cloth, lightly brush off any dust.
For additional care, dampen the cloth with warm water.
For deepest cleaning, use an Acrylic cleaner.

COASTERFURNITURE.COM

COASTER
FINE FURNITURE

Product Size : 851 X 533 X 1050 H (MM)
Product Size : 33 $\frac{1}{2}$" X 21" X 41 $\frac{1}{2}$"

21"

21"

10.83"

33"

24.69"

7/8"

10.83"

41.5"

12"

6.5"

21.65"

6.3"

5.91"

6.5"

21.65"

11.42"

8.94"

33.5"

Note : Dimension tolerance ±5%

COASTERFURNITURE.COM

COASTER®
FINE FURNITURE

| Product Size : 1600 X 883 X 1050 H (MM) |
| Product Size : 63" X 34 ¾" X 41 ½" |

34.75"

34.75"

61.61"

10.83"

45.87"

10.83"

7.8"

41.5"

12"

6.5"

5.91"

6.3"

6.5"

11.42"

8.94"

63"