


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

315985K
King Headboard

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!




1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME


15 MINUTES

PARTS IDENTIFICATION

A HEADBOARD
PANEL


1PC

B LEFT LEG




1PC

C RIGHT LEG



1PC

D WOOD CLEAT



2PCS

E HEADBOARD
BOTTOM RAIL

1PC

HARDWARE IDENTIFICATION

1 ALLEN WRENCH
(4MM-RBW)

1PC

2 BIG LOCK WASHER
(Ø 5/16 "-RBW)

12PCS

3 BIG BOLT
(Ø 5/16 "X38mm-RBW)

12PCS

4 BIG FLAT WASHER
(Ø 5/16 "-RBW)

12PCS

5 HEX NUT
(1/4"x10mm)

6PCS

6 WRENCH
(10MM-RBW)

1PC

7 SMALL BOLT
(Ø 1/4 "X38mm-RBW)

6PCS

8 SMALL LOCK WASHER
(Ø 1/4 "-RBW)

12PCS


9 SMALL FLAT WASHER
(Ø 1/4 "-RBW)

12PCS


ITEM: **315985K**

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




STEP 3

COMPLETE



ITEM:315985K



Note:Dimension tolerance $\pm$ 5%