

## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

**900821**  
**COAT RACK**

ITEM: **900821**



## ASSEMBLY INSTRUCTIONS


### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

30 MINUTES


## PARTS IDENTIFICATION

**A BASE TUBE**




1PC

**B MIDDLE TUBE**




1PC

**C TOP TUBE**



3PCS

**D LEG**



1PC

**E RING**



1PC

**F HOOK**



6PCS



### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **900821**




**HARDWARE IDENTIFICATION**

1	<b>BOLT</b> (Φ3/16"x12mm)		3PCS
2	<b>BOLT</b> (Φ3/16"x22mm)		18PCS


**NOTE:**  
Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **900821**  
**ASSEMBLY INSTRUCTIONS**  
**STEP 1**




---

**STEP 2**




ITEM: **900821**  
**ASSEMBLY INSTRUCTIONS**  
**STEP 3**



---

**STEP 4**



ITEM: **900821**

Product size:440Wx440Dx1775H(mm)

Product size:17-1/4"Wx17-1/4"Dx70"H

Ø13x480mm	Solid
Ø1/2"x18-7/8"	

Ø32x489mm	Solid
Ø1-1/4"x19-1/4"	

Ø32x600mm	Solid
Ø1-1/4"x23-5/8"	

Ø19x1039mm	Solid
Ø3/4"x40-7/8"	

Ø16x790mm	Solid
Ø5/8"x31-1/8"	

Ø32x600mm	Solid
Ø1-1/4"x23-5/8"	

