

*ASSEMBLY INSTRUCTIONS  
COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

**710888**  
**COFFEE TABLE**

# ITEM:710888

## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.







ASSEMBLY TIME

25 MINUTES

## PARTS IDENTIFICATION



## HARDWARE IDENTIFICATION

Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 15g		1 PC	4	CAM LOCK Ø15x12mm SR		12 PCS
2	WOODEN DOWEL Ø 8x30mm		14 PCS	5	PLASTIC FEET Ø15mm		4 PCS
3	CAM BOLT Ø7x35.5mm SR		12 PCS	6	STICKER Ø20mm		2 PCS





### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.




ITEM: 710888

**STEP 1**





**COASTER**  
FINE FURNITURE



Apply glue on all wooden dowels to ensure integrity of the structure.




INCORRECT  
CORRECT





ITEM: **710888**

## **STEP 2**



**COASTER**  
FINE FURNITURE



Apply glue on all wooden dowels to ensure integrity of the structure.




## **STEP 3**




ITEM: **710888**

**STEP 4**

**COMPLETE**



ITEM: 710888



**Note :** Dimension tolerance  $\pm 5\%$