



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

551911
ARMLESS CHAIR

ITEM: 551911

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!




1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES


PARTS IDENTIFICATION

	PART NAME	FIGURE	QUANTITY
A	ARMLESS CHAIR		1PC
B	PILLOW		2PCS
C	LEG		4PCS


ITEM: 551911

ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2



STEP 3




STEP 4



ITEM: 551911


ASSEMBLY INSTRUCTIONS

STEP 5




COASTER
FINE FURNITURE


STEP 6




STEP 7



STEP 8



ITEM: 551911



Note : Dimension tolerance $\pm 5\%$

