

*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

706177
END TABLE

ITEM:706177

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

30 MINUTES


PARTS IDENTIFICATION

A MIDDLE PANEL




1 PC

C BOTTOM PANEL




1 PC

B SIDE PANEL



2 PCS

D TOP PANEL



1 PC

HARDWARE IDENTIFICATION

Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	WOODEN DOWEL Ø8x30mm		13 PCS	4	BOLT Ø9.5x55mm SR		7 PCS
2	CAM BOLT Ø7x35.5mm SR		6 PCS	5	FOOT Ø35xH19mm		4 PCS
3	CAM LOCK Ø15x12mm SR		6 PCS	6	STICKER Ø20mm		1 PC

Z5 not included in blister packaging.



NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.




ITEM: **706177**

STEP 1


COASTER
FINE FURNITURE



STEP 2






INCORRECT
CORRECT






Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM: **706177**

STEP 3






STEP 4





ITEM: **706177**

STEP 5

COASTER
FINE FURNITURE





STEP 6



ITEM: **706177**




STEP 7


COASTER
FINE FURNITURE



STEP 8

COMPLETE





Note : Dimension tolerance $\pm 5\%$

*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

706178
COFFEE TABLE

ITEM:706178

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

30 MINUTES


PARTS IDENTIFICATION

A MIDDLE PANEL




1 PC

C BOTTOM PANEL




1 PC

B SIDE PANEL



2 PCS

D TOP PANEL



1 PC

HARDWARE IDENTIFICATION

Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	WOODEN DOWEL Ø8x30mm		15 PCS	4	BOLT Ø9.5x55mm SR		9 PCS
2	CAM BOLT Ø7x35.5mm SR		6 PCS	5	FOOT Ø35xH19mm		5 PCS
3	CAM LOCK Ø15x12mm SR		6 PCS	6	STICKER Ø20mm		1 PC



Z5 not included in blister packaging.

NOTE:




Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **706178**


STEP 1




STEP 2



INCORRECT
CORRECT





Apply glue on all wooden dowels to ensure integrity of the structure.







ITEM: **706178**

STEP 3

COASTER
FINE FURNITURE





STEP 4





ITEM: **706178**

STEP 5

COASTER
FINE FURNITURE





STEP 6



ITEM: **706178**




STEP 7

COASTER
FINE FURNITURE




STEP 8

COMPLETE



ITEM: 706178



Note : Dimension tolerance $\pm 5\%$