

*ASSEMBLY INSTRUCTIONS*  
*COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

900250  
***SNACK TABLE***

REVISION 0 : 09/15/2017  
REVISION 1 : 05/09/2023

ITEM:900250



# ASSEMBLY INSTRUCTIONS

## ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.








## WARNING!






1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 30 MINUTES

## PARTS IDENTIFICATION

A	TOP GLASS		1PC
B	TOP FRAME		1PC
C	BOTTOM FRAME		1PC
D	BACK CROSSBAR		2PCS
E	FRONT CROSSBAR		2PCS

## HARDWARE IDENTIFICATION


1	BOLT (1/4" x 32mm SR)		4PCS	4	FLOOR PROTECTOR (Ø6.3mm)		4PCS
2	SCREW (3/16" x 12mm SR)		6PCS	5	ALLEN WRENCH (4mm)		1PC
3	SUCTION CUP (Ø6mm)		4PCS				

# ITEM: 900250 ASSEMBLY INSTRUCTIONS




## STEP 1


Do not tighten until each step is completed or instructed.




## STEP 2




ITEM: 900250  
**ASSEMBLY INSTRUCTIONS**  
STEP 3



STEP 4



COMPLETE




# ITEM:900250

## ASSEMBLY INSTRUCTIONS



**Product Size : 254 X 457 X 610 H (MM)**

**Product Size : 10" X 18" X 24"**



Note : Dimension tolerance  $\pm 5\%$