

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

950403 SHOE CABINET

REVISION 0 : 10/25/2023 REVISION 1 : 06/26/2024

PAGE 1 OF 14

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

Remove hardware from box and sort by size.
 Please check to see that all hardware and parts are present prior to start of assembly.
 Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

60 MINUTES

PARTS IDENTIFICATION

A	LEFT SIDE PANEL	1 PC	G	BACK CROSSBRACE	2 PCS
В	RIGHT SIDE PANEL	1 PC	н	UPPER BACK PANEL	3 PCS
С	BOTTOM PANEL	1 PC	ı	LOWER BACK PANEL	1 PC
D	CROSS PANEL	1 PC	J	SHELF	3 PCS
E	TOP PANEL	1 PC	к	PARTITION PANEL	6 PCS
F	UPPER CROSSBRACE	1 PC	L	DOOR	3 PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.




HARDWARE IDENTIFICATION

Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	11	PLASTIC SIDE SCREW Ø8x17mm		6 PCS
2	WOODEN DOWEL Ø8x30mm		22 PCS	12	BOLT Ø5x15mm		6 PCS
3	CAM BOLT Ø7x35.5mm SR		12 PCS	13	SCREW Ø4x15mm SR	attitt(®	18 PCS
4	CAM LOCK Ø15x12mm SR		12 PCS	14	FIXER		6 PCS
5	SCREW Ø4.5x42mm SR	attitute &	4 PCS	15	FIXER SCREW Ø3x19mm SR	A STATE OF THE STA	24 PCS
6	HANDLE L=120mm		3 PCS	16	FOOT Ø35xH19mm		4 PCS
7	HANDLE BOLT Ø4x28mm SR	E CONTRACTOR OF THE PARTY OF TH	6 PCS	17	WALL PLUG 6x30mm	a side	4 PCS
8	PLASTIC SIDE		3 PCS	18	SCREW Ø4.3x35mm SR	antituttitute (M	4 PCS
9	LATCH-MALE		6 PCS	19	STICKER Ø20mm		2 PCS
10	LATCH-FEMALE		6 PCS				

Z6,Z7,Z8,Z16 not included in blister packaging.


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.













COASTERFURNITURE.COM







PAGE 5 OF 14



































PAGE 9 OF 14

COASTERFURNITURE.COM
















































Note: Dimension tolerance ±5%



ANTI-TIPPING INSTALLMENT INSTRUCTIONS FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.

This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.


This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

This restraint must be screwed to a wood stud on the wall, using the long screw provided.


STEP 1

Secure the bracket to the back top of the unit, using the short screw provided, as shown in the drawing.



STEP 2

Locate the wood stud on the wall, and secure the other bracket, 2 inches below the back of the unit.



STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end, and drag it through, until the slack is removed. Ensure that the strap is securely laced and locked.

