

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

121186 Counter Chair

REVISION 0 : 12/18/2023 REVISION 1 : 10/25/2024 REVISION 2 : 09/16/2025

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION



HARDWARE IDENTIFICATION

1	LONG BOLT (1/4" x 50mm - BLK)		4PCS	4	LOCK WASHER (Ø1/4" - BLK)	4PCS
2	SHORT BOLT (1/4" x 30mm - BLK)		12PCS	5	FLAT WASHER (Ø1/4" - BLK)	4PCS
3	PAN HEAD SCREW (5/32" x 9mm - BLK)	€ mma	4PCS	6	ALLEN WRENCH (4mm - BLK)	1PC

NOTE:

Quantities shown are for one chair.


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

COASTER


ASSEMBLY INSTRUCTIONS

STEP 1

Do not fully tighten all bolts until assembly is complete.



STEP 2




PAGE 3 OF 5


COASTERFURNITURE COM

COASTER

ASSEMBLY INSTRUCTIONS STEP 3



STEP 4




PAGE 4 OF 5

COASTERFURNITURE.COM

COASTER

ASSEMBLY INSTRUCTIONS STEP 5



STEP 6 COMPLETE






PAGE 5 OF 5

COASTERFURNITURE.COM





Note: Dimension tolerance ± 5%